SAFETY INSTRUCTIONS FOR HARDWIRED PENDANT

PACKAGE CONTENTS



PART	DESCRIPTION	QUANTITY
A	Mounting Strap	1
B	Canopy	1
C	Pendant Lamp Set	1

HARDWARE CONTENTS



Screw

Qty.2



Screw Anchors

Qty.2



Mounting Strap

Qty.1

Hardware

Qty.2

⚠ SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product

WARNING .

- TURN OFF ELECTRICITY at main fuse box (or circuit breaker box) before beginning installation by removing fuse (or switching off circuit breaker)

CAUTION

- CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.
- If in doubt about electrical installation, consult a licenced electrician.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents above. If any part is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

ASSEMBLY INSTRUCTIONS

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX / CIRCUIT BREAKER
2. REMOVE ALL PARTS FROM CARTON. DO NOT THROW AWAY ANY PARTS.
3. ATTACH THE **HOOK** ON ONE SIDE OF THE CHAIN TO THE **PENDANT HOOK**
4. UNSCREW THE CONNECTOR AND LOOSEN THE CORD GRIP AND INSERT THE CORD IN THE MOUNTING STRAP THROUGH THE CANOPY, TIGHTEN THE CORD GRIP
5. ATTACH THE BLACK COLOURED WIRE TO PHASE, WHITE COLOURED WIRE TO NEUTRAL AND GREEN COLOURED WIRE TO EARTH
6. FIX THE MOUNTING STRAP TO THE PLASTER/ DRY OR SIMILAR CEILING PROPERLY WITH HARDWARE PROVIDED.
7. FIX THE CANOPY TO THE MOUNTING STRAP AS SHOWN ABOVE, AND LOCK WITH HARDWARE PROVIDED.
8. CAREFULLY LOWER THE **LAMP** ALONG WITH THE **METAL CHAIN** UNTIL THE **METAL CHAIN** IS TAUT. STRAIGHTEN THE **METAL CHAIN** LINKS.

CARE AND MAINTENANCE

- Shut off the main power supply before wiping product with damp cloth or window cleaner. Do not use abrasives.
- Bulb replacement: Use 60-watt or less standard-base bulbs.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Bulb won't light	1. Bulb is burned out 2. Power is off 3. Faulty wire connection. 4. Faulty switch.	1. Replace light bulb. 2. Make sure power supply is on. 3. Check wiring.
Fuse blows or circuit breaker trips when light is turned on	Crossed wires or power wire is grounding out.	Check wire connections.